

**Table Of Contents**

<b>Table Of Contents -----</b>	<b>TOC-1</b>
<b><u>Chapter 1 – Basic MX Concepts</u></b>	
Models, Strings, and Points -----	1-1
String Labels -----	1-2
MX Structure -----	1-2
Command Language -----	1-2
Linemode -----	1-3
Model Naming Convention -----	1-3
Drawings Versus Displays -----	1-4
Style and Feature Sets -----	1-4
Starting The Software -----	1-5
The Graphical User Interface(GUI) -----	1-6
The Zoom Toolbar -----	1-7
The Menu Bar -----	1-8
Journal Files -----	1-9
Output Files -----	1-11
Compressing The Model File -----	1-12
<b><u>Chapter 2 – Setting Up A New MX Project</u></b>	
New MX Project Setup Utility -----	2-1
About The Survey Input Files -----	2-2
Manual Method For Project Setup -----	2-3
Start MX With New Project From MX Start Panel -----	2-3
<b><u>Chapter 3 – Displaying / Drawing the GROUND Model</u></b>	
Create A New Plan Display -----	3-1
Assign Style and Feature Sets To A Model -----	3-1
Display the GROUND Model -----	3-3
Create A Plan Page Layout -----	3-4
MDOT Draw Plan Pages -----	3-7
The INPUT File Created By MDOT Draw Plan Pages -----	3-9
<b><u>Chapter 4 – Horizontal Alignment</u></b>	
The Horizontal Element Method Theory-----	4-1
Creating The Horizontal Alignment in MX-----	4-2
Planning Your Horizontal Alignment Strategy-----	4-5
<i>Fixed Elements</i> -----	4-7
<i>Floating Elements</i> -----	4-7
<i>Free Elements</i> -----	4-9
<i>Add Straight/Add Arc</i> -----	4-10
<i>Special Geometry</i> -----	4-11
<i>Edit Alignment</i> -----	4-11
<i>Clearance Checking</i> -----	4-14
<i>Create HALGN Data</i> -----	4-14
<i>Create Master String</i> -----	4-15
Retrieving and Alignment from an HALGN or GENIO File-----	4-16
Creating Side Road Alignments-----	4-18
All About MX Point Selection Methods (PSM's)-----	4-20
The Quick Horizontal Alignment Method -----	4-25
<b><u>Chapter 5A – Create-View-Draw Profiles</u></b>	
Creating Profile Strings with an INPUT File-----	5A-2
Creating And Viewing Profiles with The Profile Viewer-----	5A-3
Drawing Profiles Using an INPUT File -----	5A-9
Creating a Profile Drawing using MDOT Create-Draw Profile.exe-----	5A-10

**Chapter 5A – Vertical Alignments**

Define Vertical Geometry using Major Option VERAT-----	5B-1
Define Vertical Geometry using Major Option VCUSP -----	5B-2
Quick Vertical Alignment -----	5B-4
MX Vertical Alignment Text Editor-----	5B-9
Vertical Element Method -----	5B-10

**Chapter 6 – Create And Draw Cross-Sections**

Create-View Cross Sections with the MX Cross Section Viewer-----	6-1
Create Cross Sections – INPUT File Method -----	6-7
Drawing Cross Sections With MDOT Draw Cross Section.exe-----	6-9
Drawing Cross Sections With INPUT Files -----	6-11

**Chapter 7 – Create Roadway Template**

MXRoad Method -----	7-1
Create Template Strings Using An INPUT File -----	7-5
Creating Roadway Strings Using <i>Design A String</i> -----	7-9

**Chapter 8 – Road Widening**

MXRoad Road Widening Wizard -----	8-1
-----------------------------------	-----

**Chapter 9 – Superelevation**

Superelevating The Roadway Using Rule-Based Superelevation -----	9-1
Superelevating The Roadway With An INPUT File -----	9-3

**Chapter 10 – Intersection Design**

MXRoad Create Curb Return -----	10-1
MXRoad Regrade Intersection -----	10-3
MXRoad Create Traffic Island -----	10-4
MXRoad Tidy Intersection -----	10-6
Manual Method Of Creating Intersections -----	10-6
Summary Of Intersection Design -----	10-11

**Chapter 11 – Create Shoulders, Curbs, Sidewalks, etc.**

Creating Shoulders for Superelevated Roadways -----	11-1
Shoulder, Curb, and Sidewalk Design – R/C or Less -----	11-3

**Chapter 12 – Creating Driveway Strings**

The MDOT Driveway String Naming Convention -----	12-1
Executing The MDOT Driveway Design Add-In -----	12-2
Evaluation Of Heavily-Skewed Driveways -----	12-5

**Chapter 13 – Interfacing Proposed Design To Existing Ground**

Interfacing With The MXRoad Earthworks Wizard -----	13-1
Interfacing Using The INPUT File Method -----	13-3
Creating a Standard V-Ditch -----	13-5
Creating A Standard Berm Behind Curb -----	13-6

**Chapter 14 – The Cross Sectional Editor****Chapter 15 – Subgrade Design**

The INPUT File Method Of Creating Subgrade Strings -----	15-1
Pavement And Subgrade Design Wizard method -----	15-3

**Chapter 16 – Determine Cut/Fill Volumes**

The INPUT File Method -----	16-1
-----------------------------	------

**Chapter 17 – Create MDOT Reports**

Horizontal Alignment Reports -----	17-1
Station-Offset Reports -----	17-2

**Chapter 18 – Backing Up MX Project Data****Chapter 19 – Create / Transfer Drawings To MicroStation with MXChange**

Creating Drawings For MXChange Translations -----	19-1
Configuring MicroStation for MXChange Translations-----	19-5
Starting MicroStation -----	19-5
Setting the MXChange Import Preferences -----	19-8
Importing MX Drawings (General Procedure) -----	19-11

MXChange Settings Summary Table -----	19-12
<b>Appendix A – General MX Plotting Information</b>	
Printer Definitions And Drivers -----	A-1
Creating Custom Form Sizes -----	A-1
MX Page Setup -----	A-2
<b>Appendix B – Sending Plots To an OCE 9400, OCE 9800, or an HP 750C Plotter.</b>	
<b>Appendix C – The MX Standard String Naming Convention</b>	
<b>Appendix D – MX Online Help How-To's</b>	
<i>Alignment How-To's</i> -----	D-1
Create a three center curve -----	D-1
Move a point of intersection -----	D-2
Retrieve an alignment -----	D-2
<i>Creating And Applying Styles How-To's</i> -----	D-3
Apply current styles to an existing display -----	D-3
Create a new cross hatching fill style -----	D-3
Create a new dashed line style -----	D-4
Create a new line hatching fill style -----	D-4
Create a new macroline style -----	D-5
Create a new symbol fill style, random position, fixed angle ---	D-5
Create a new symbol fill style, random position, random angle- -----	D-6
Create a new symbol fill style, fixed spacing and angles -----	D-6
Create a new text style -----	D-7
Delete a fill style -----	D-8
Delete a line style -----	D-8
Delete a text style -----	D-8
Edit an existing fill style -----	D-8
Edit an existing line style -----	D-9
Edit an existing text style -----	D-9
Set the current curve fitting style -----	D-9
Set the current fill color -----	D-10
Set the current fill pattern -----	D-10
Set the current line color -----	D-10
Set the current line style -----	D-10
Set the current line width -----	D-11
Set the current text color -----	D-11
Set the current text line width -----	D-11
Set the current text style -----	D-11
<i>Display / Draw How-To's</i> -----	D-12
Annotate null/zero elevations on a string -----	D-12
Annotate pips at string points -----	D-12
Create a plan working display or an existing model -----	D-13
Display a grid -----	D-13
Display annotation along a string -----	D-14
Display annotation at string points -----	D-14
Display area fill between strings -----	D-15
Display area fill inside a string -----	D-16
Display cadastral strings and symbols -----	D-16
Display station annotation -----	D-17
Display contour strings -----	D-17
Display cross slope annotation in Plan -----	D-18
Display earthworks string with annotation -----	D-19
Display inlets -----	D-19
Display manholes -----	D-20
Display master alignment strings -----	D-20
Display pipes -----	D-21

---

Display point strings -----	D-21
Display scaled symbols at string points -----	D-22
Display spot elevations at string points -----	D-23
Display strings in current style -----	D-23
Display symbols at string points -----	D-24
Display text strings -----	D-24
Display triangulation models -----	D-25
Display vertical point of intersection annotation in plan -----	D-25
Edit a saved page setup -----	D-26
Edit a set of layout pages -----	D-26
Open a stored set of layout pages -----	D-27
Orient text and pips -----	D-27
Orient text and pips for geometry strings -----	D-28
Place pages with Autopage -----	D-29
Place pages with Auto string -----	D-29
Place pages with Add page -----	D-29
Place pages with Next page -----	D-30
Reorder a set of layout pages -----	D-30
Reset a page setup to the default settings -----	D-31
Restrict the area of the model to be displayed or drawn -----	D-31
Save a page layout -----	D-31
Save a page setup -----	D-31
Adding Text to a drawing -----	D-32
Adding symbols to a drawing -----	D-32
Enhancing one page or all pages in a drawing -----	D-33
<b>Earthworks How-To's-----</b>	D-33
Create a custom earthwork style -----	D-33
Ignore intersections with ground model -----	D-34
Modify an element of an earthwork style -----	D-34
Select an element of an earthwork style to edit -----	D-35

### **MDOT MX User Notes**

<b>FLY-1</b>	<b>Creating a Fly-Through with 3D Model Viewer</b>
<b>SEC-1</b>	<b>Using the Dynamic Section Viewer</b>
<b>SEC-2</b>	<b>Annotating Pipes in Cross Sections</b>
<b>TXT-1</b>	<b>Using Survey Text Groups</b>
<b>URB-1</b>	<b>Using The MDOT Urban Match Module</b>
<b>GEO-1</b>	<b>Creating a Geometric Layout (Geometry.dpw)</b>